









FORD FALCON Wagon - 2WD

XE-XF 6 Cyl & V8, EA-EL 6 Cyl, EB-EL V8, AU 6 Cyl & V8, BA-BF, BF MK II & III

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
	Gas Shocks - XE to XF		SAB28160		F R O N T
	Gas Struts - EA to EL		SAB28240	2 ea	
	Gas Struts - AU I, II, III		SAB28800		
	Gas Struts BA to BF		SAB36690		
COIL SPRINGS					
	Standard Height Plus Heavy Duty Coil Springs	20mm	H/Duty Coil available on request for each model	1 pr	
SHOCK ABSORBERS					
	Gas Shock Absorbers - XE to EL		SAB28220	2 ea	R E A R
	Gas Shock Absorbers - AU to BF		SAB36670		
LEAF SPRINGS					
	Raised Height Heavy Duty 6 Leaf Springs Fixed end eye = 54mm must use BlueMax bush kit with these springs	15-20mm	FORD020	2 ea	
SHACKLE BUSH KITS					
	Polyurethane Bush Kit		BU744UK	1 kit	
U-BOLTS					
	Early Models up to BA Round Form U Bolts - With Nuts UB258 = 230mm x 75mm x 7/16" round UB258L = 260mm x 75mm x 7/16" round After BA Round Form U Bolts - With Nuts UB458 = 190mm x 75mm x 9/16" round		UB258 UB258L UB458	4 ea	
SANDWICH PLATES					
	U Bolt Sandwich Plates - sold in pairs		SPS-FORD	2 pr	