







FORD FALCON Utility - 2WD

AU, BA-BF, FG Ute **Not Suitable for RTV Utilities**

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
	AU, AU11-A11 V6 & V8, XR6 & XR8 Ute		SAB28800		F R O N T
	BA to BF - ALL Utes		SAB36690	2 ea	
	FG-XR6 & XR8 & XR6 Turbo & R6 Ute		SA673637G		
COIL SPRINGS					
	Standard Height Plus Heavy Duty Coil Springs	40mm	H/Duty Coil available on request for each model	1 pr	
SHOCK ABSORBERS					
	AU-BF - 07/1999 to 09/2006		SAB36660	2 ea	R E A R
	FG-XR6 & XR8 & XR6 Turbo Ute - 02/2008 Onwards		SAS314317	1 R	
	FG-R6 Ute - 02/2008 Onwards		SAS314316 SAS314315	1 L 2 ea	
LEAF SPRINGS					
	Raised Height Heavy Duty 4 + 2 Leaf Springs		FORD021		2 ea
	Raised Height Extra Heavy Duty 5 + 2 Leaf Springs Fixed end eye = 54mm must use BlueMax bush kit with these springs	25-30mm	FORD021M		
SHACKLE BUSH KITS					
	Polyurethane Bush Kit		BU744UK	1 kit	
U-BOLTS					
	Round Form U Bolts - With Nuts				4 ea
	UB458 = 190mm x 75mm x 9/16" round		UB458		
	UB458-1 = 210mm x 75mm x 9/16" round		UB458-1		
	OR UB453-1 = 215mm x 83mm x 9/16" round		UB453-1		
SANDWICH PLATES					
	U Bolt Sandwich Plates - sold in pairs FORD021 2pr FORD021M 4pr		SPS-FORD	2/4pr	
POLYAIR SPRINGS					
	Polyair Bellows Kit	STD	PA85111	1 kit	