





# FORD EXPLORER - 4WD

UT, UX, UZ V6 & V8 Models 2001 to 2005

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
<b>SHOCK ABSORBERS</b>					
	30mm Gas Shock Absorbers (Sachs)		<b>SAS030320</b>	2 ea	<b>F R O N T</b>
<b>COIL SPRINGS</b>					
	Raised Height Coil Springs <b>6 Cylinder Engine</b>	25mm	<b>FOR-208</b>	1 pr	
	Raised Height Coil Springs <b>V8 Engine</b>		<b>FOR-208SP</b>		
<b>SHOCK ABSORBERS</b>					
	35mm Gas Shock Absorbers	25mm	<b>SAS030321</b>	2 ea	<b>R E A R</b>
<b>COIL SPRINGS</b>					
	Raised Height Coil Springs <b>6 Cylinder &amp; V8 Engine</b>	25mm	<b>FOR-209</b>	1 pr	