










# FORD COURIER / RANGER - 4WD

1987 to 11/2006

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
<b>SHOCK ABSORBERS</b>						
	35mm Gas Bulged Shock Absorbers	STD	<b>SA35667GL</b>	2 ea	<b>F R O N T</b>	
	35mm Gas Bulged Shock Absorbers	RSD	<b>SA35643G</b>			
<b>TOP SHOCK BRACKET</b>						
	Shock Absorber Upper Reinforcement Bracket 2/1999 Onwards - strongly recommended when fitting upgraded shock absorbers		<b>SHOCKBRKT -MAZ1</b>	1 kit		
<b>TORSION BARS</b>						
	Increased Rate Torsion Bars Length 989mm		<b>MAZDA005</b>	1 pr		
<b>SHOCK ABSORBERS</b>						
	35mm Gas Bulged Shock Absorbers		<b>SA35095G</b>	2 ea		
<b>LEAF SPRINGS</b>						
	Raised Height Extra Heavy Duty 5 + 2 Leaf Springs Overslung	50mm	<b>MAZDA016</b>	2 ea		
<b>SHACKLE BUSH KITS</b>						
	Polyurethane Bush Kit		<b>BU756UK</b>	1 kit	<b>R E A R</b>	
<b>U-BOLTS</b>						
	Round Form U Bolts - With Nuts		<b>UB453-1</b>	4 ea		
<b>SHACKLES</b>						
	Greaseable Shackles		<b>S386-1K</b>	2 ea		
<b>PINS</b>						
	Greaseable Pins		<b>P794</b>	2 ea		