











# FORD MAVERICK - 4WD

Y60 SWB Hardtop 1988 to 1994

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
<b>SHOCK ABSORBERS</b>						
	35mm Gas Bulged Shock Absorbers		<b>SA35091GL</b>	2 ea	<b>F R O N T</b>	
	41mm Foam Cell Shock Absorbers		<b>SA41091FCN</b>			
<b>STEERING DAMPER</b>						
 <i>check end type</i>	Steering Damper - Pre 9/1989	Eye/Eye	<b>SD14034G</b>	1 only		
	Expanded Body Steering Damper - 9/1989 Onwards	Pin/Pin	<b>SD35036G</b>			
<b>COIL SPRINGS</b>						
	Raised Height Heavy Duty Coil Springs <b>No bar / winch</b>	50mm	<b>NIS-200</b>	1 pr		
	Raised Height Heavy Duty Coil Springs <b>With bar / winch</b>		<b>NIS-201</b>			
<b>CASTER BUSH KIT</b>						
	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		<b>BU1721UK</b>	1 kit		
<b>PANHARD RODS</b>						
	Adjustable Panhard Rod		<b>PRNISS004F</b>	1 ea		
<b>SHOCK ABSORBERS</b>						
	35mm Gas Bulged Shock Absorbers		<b>SA35094GL</b>	2 ea	<b>R E A R</b>	
	41mm Foam Cell Shock Absorbers		<b>SA41094FC</b>			
<b>COIL SPRINGS</b>						
	Raised Height Heavy Duty Coil Springs LBA 100KG to GVM	50mm	<b>NIS-213</b>	1 pr		
	Raised Height Heavy Duty Coil Springs LBA 150KG to GVM		<b>NIS-214</b>			
<b>PANHARD RODS</b>						
	Adjustable Panhard Rod		<b>PRNISS005R</b>	1 ea		