



















# FORD F250 - 4WD

2000 Onwards

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
<b>SHOCK ABSORBERS</b>						
	35mm Gas Bulged Shock Absorbers		<b>SA830963AT</b>	2 ea	<b>F R O N T</b>	
	46mm Mono Tube Shock Absorbers		<b>SA46963G</b>			
<b>LEAF SPRINGS</b>						
	Raised Height Heavy Duty Parabolic Springs <b>3 Leaf</b>	50mm	<b>FORD033P3</b>	2 ea		
	Raised Height Extra Heavy Duty Parabolic Springs <b>4 leaf - use with extreme loads</b>		<b>FORD033P4</b>			
<b>SHACKLE BUSHES</b>						
	Silent Block Bush - Shackle Pin Upper & Lower		<b>BU149</b>	4 ea		
	Silent Block Bush - Fixed Pin		<b>BU150</b>	2 ea		
	also available as Polyurethane Bush Kit		<b>BU740UK</b>	1 kit		
<b>U-BOLTS</b>						
	Square Form U Bolts - With Nuts		<b>UB471</b>	4 ea		
<b>PANHARD RODS</b>						
	Adjustable Panhard Rod		<b>PRF250</b>	1 ea		
<b>SHOCK ABSORBERS</b>						
	<b>Quad Suspension</b> 35mm Hydraulic Shock Absorbers		<b>SA83314AT</b>	4 ea		
	46mm Mono Tube Shock Absorbers		<b>SA46314G</b>			
<b>LEAF SPRINGS</b>						
	Raised Height Heavy Duty 4 + 2 Leaf Springs	50mm	<b>FORD031</b>	2 ea		
	Raised Height Heavy Duty 5 + 2 Leaf Springs		<b>FORD031M</b>			
<b>SHACKLE BUSHES</b>						
	Silent Block Bush - Shackle Pin Upper & Lower		<b>BU149</b>	4 ea		
	Silent Block Bush - Fixed Pin		<b>BU150</b>	2 ea		
	also available as Polyurethane Bush Kit		<b>BU740UK</b>	1 kit		
<b>U-BOLTS</b>						
	Round Form U Bolts - With Nuts		<b>UB472</b>	4 ea		
	Round Form U Bolts - With Nuts <b>use with FORD031M</b>		<b>UB472-1</b>			
<b>POLYAIR SPRINGS</b>						
	Polyair Bellows Kit F250, F350 2000 onwards 4 shock rear	RSD	<b>PA85301</b>	1 kit		
	Spacer Bracket <b>use with RSD suspension</b>		<b>SP-F250</b>	4 ea		
	Square Form U Bolts - With Nuts <b>to suit spacer bracket</b>		<b>UB381</b>	4 ea		