


















FORD F350 - 4WD

2000 Onwards

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
SHOCK ABSORBERS						
	35mm Gas Bulged Shock Absorbers		SA830963AT	2 ea	F R O N T	
	46mm Mono Tube Shock Absorbers		SA46963G			
LEAF SPRINGS						
	Raised Height Heavy Duty Parabolic Springs 3 Leaf	50mm	FORD033P3	2 ea		
	Raised Height Extra Heavy Duty Parabolic Springs 4 leaf - use with extreme loads		FORD033P4			
SHACKLE BUSHES						
	Silent Block Bush - Shackle Pin Upper & Lower		BU149	4 ea		
	Silent Block Bush - Fixed Pin		BU150	2 ea		
	also available as Polyurethane Bush Kit		BU740UK	1 kit		
U-BOLTS						
	Square Form U Bolts - With Nuts		UB471	4 ea		
PANHARD RODS						
	Adjustable Panhard Rod		PRF250	1 ea		
SHOCK ABSORBERS						
	35mm Hydraulic Shock Absorbers		SA83314AT	2 ea		
	46mm Mono Tube Shock Absorbers		SA46314G			
LEAF SPRINGS						
	Raised Height Heavy Duty Leaf Springs	50mm	FORD038	2 ea		
SHACKLE BUSHES						
	Silent Block Bush - Shackle Pin Upper & Lower		BU149	4 ea	R E A R	
	Silent Block Bush - Fixed Pin		BU150	2 ea		
	also available as Polyurethane Bush Kit		BU740UK	1 kit		
U-BOLTS						
	Round Form U Bolts - With Nuts		TBA	4 ea		
POLYAIR SPRINGS						
	Polyair Bellows Kit F250, F350 2000 onwards 4 shock rear	RSD	PA85301	1 kit		