









# MITSUBISHI TRITON - 4WD

MQ 5/2015 Onwards

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
<b>STRUT / COIL ASSEMBLY</b>					
	Preassembled Strut/Coil With Top Plate Mount		<b>Nominate coil fitment</b>	2 ea	
<b>STRUT / SHOCK ABSORBERS</b>					
	Strut/Gas Spring Seat Shock Absorbers		<b>SA67330G</b>	1 pr	
<b>COIL SPRINGS</b>					
	Raised Height Heavy Duty Tapered Coils <b>Progressive Rate - No Bar / Winch</b>		<b>MIT-207T</b>		
	Raised Extra Height Heavy Duty Tapered Coils <b>Progressive Rate - With Bar / Winch</b>	50mm	<b>MIT-207H</b>	1 pr	
	Raised Height Extra Heavy Duty Tapered Coils <b>Extreme loads only</b>		<b>MIT-207HD</b>		
<b>TOP PLATE MOUNT</b>					
	Strut Top Plate Mount		<b>TPL4075</b>	2 ea	
<b>TAIL SHAFT SPACER KIT</b>					
	Use this kit with raised suspensions to correctly align the tailshaft centre bearing on 2 piece tailshafts. Contains: 1 x spacer - 2 x wedges - 4 x bolts, nuts, washers		<b>SPKITTRIT</b>	1 kit	
<b>SHOCK ABSORBERS</b>					
	35mm Gas Bulged Shock Absorbers		<b>TBA</b>	2 ea	
<b>LEAF SPRINGS</b>					
	Raised Height Heavy Duty 5 + 2 Leaf Springs		<b>TBA</b>		
	Raised Height Heavy Duty 6 + 2 Leaf Springs	50mm	<b>TBA</b>		
	Raised Height Extra Heavy Duty 7 + 2 Leaf Springs <b>with 10mm main &amp; wrap leaves - constant loads</b>		<b>TBA</b>	2 ea	
<b>SHACKLE BUSH KITS</b>					
	Polyurethane Bush Kit		<b>TBA</b>	1 kit	
<b>U-BOLTS</b>					
	Square Form U Bolts With Nuts - ML <b>1/2" material</b>		<b>TBA</b>		
	Square Form U Bolts With Nuts - MN <b>9/16" material</b>		<b>TBA</b>	4 ea	
<b>SHACKLES</b>					
	Greaseable Shackles		<b>TBA</b>	2 ea	
<b>PINS</b>					
	Greaseable Pins		<b>TBA</b>	2 ea	
<b>POLYAIR SPRINGS</b>					
	Polyair Bellows Kit - <b>Only run a No Drill airbag kit</b>	STD	<b>PA88129</b>		
		RSD	<b>PA88129R</b>	1 ea	

FRONT

REAR